




Buried-free Tire Killer User Manual





Content

1. Main technical parameters
- 2, the composition of the tyre breaker
- 3, construction installation and material list
- 4, the controller diagram
- 5, linkage device connection method
- 6, the connection method of the button switch
- 7, the connection method of the tyre breaker and the traffic light
8. Connection of tyre broken device and alarm
- 9, power failure and manual usage



Parameters


Components:

1. Scope of application Safety protection at intersections in key areas
2. Overall material A3 all-steel production
3. Surface treatment, spray paint and reflective paper
4. Protection grade IP67
5. The designated color is black and yellow
6. Equipment length (intercept width) can be customized
7. Equipment width Width: 520mm
8. The height of protruding ground 70~90mm
9. The maximum load-bearing weight is 100 tons
10. Height of broken tire blade 120mm
11. Blade thickness of broken tire 10mm
12. Movement form: electromechanical
13. Working environment $-40^{\circ}\text{C} \sim +70^{\circ}\text{C}$
14. Lifting control Short-range wireless remote control/wire control
15. Control distance $\leq 100\text{M}$
16. The remote control range is within 50M
17. Traffic light connection
18. Linkage with barriers
19. Material thickness: 16mm
20. The whole board is formed and bent







Technical Parameters:


1. System control: 220V electric drive
3. Power supply: 220 (control voltage 12V).
4. System power (w): 180W.
5. Rise time: $\leq 1-2S$
6. Falling time: $\leq 1-2S$
7. Working temperature: $-35^{\circ}C \sim 75^{\circ}C$ (suitable).
8. Storage environment: $-10^{\circ}C \sim 65^{\circ}C$, rain-proof, moisture-proof and dust-proof.
9. Material: A3 steel, sprayed with anti-rust primer.
10. Color: a variety of colors
11. Weight: 0.5 tons
12. Body specifications: standard chassis (size can be customized design)
Length 3000×Width 520×Height 85, lifting height: 150
Length 3500×Width 520×Height 85, lifting height: 150
Length 4000×Width 520×Height 85, lifting height: 150
Length 4500 × width 520 × height 85, lifting height: 150
Length 5000×Width 520×Height 85, lifting height: 150
Length 6000×Width 520×Height 85, lifting height: 150



Tire killer composition


1. Tire Breaker
2. Controller
3. Motor
4. Remote control





Construction installation and material list


1. Install the equipment location according to customer requirements
2. Find the two horizontal ends $\pm 10\text{mm}$
3. Prepare M12 expansion screws
4. Provide AC220V power supply (2 core 1.5-2.5 square wire)
5. Switch signal line (4 cores 1 square wire) (4 cores are: 1. common end 2. rise 3. fall 4 stop)





Controller diagram





Linkage connection

1. The linkage device and the tire breaker (parking system, access control system, license plate recognition system) can be realized, the premise is the switch signal.


2, as shown below

Picture: such as linkage parking barrier

1. The common terminal is connected to the tyre breaker controller 0V


2. The barrier is open and connected to the tyre breaker controller. Off (the barrier is raised and opened, the tyre breaker is lowered and closed, and vehicles pass through)


The barrier is closed and the tyre breaker controller is on (the barrier is lowered and closed, and the tyre breaker is raised and opened to block the vehicle)





How to connect the button switch







1、 Connection of tire killer and traffic light

2. Please use DC12V traffic lights

3. The connection method is as shown below (the wiring diagram of the traffic light of the tire breaker)


破胎器红绿灯接线图





Alarm connection method

1. Please use AC220V alarm
2. Connect the motor with anyway or forward rotation





Power failure and manual usage

1. Emergency use method after power failure
1. First open the motor box
2. Rotate the motor steering wheel by hand
3. Forward rotation rises, reverse rotation declines

